

TABLE OF CONTENTS

TTCJAN2021

CHAPTER 1 FEATURES

TOLTEC V7.0 1-1

CHAPTER 2 INSTALLATIONS

A. INTRODUCTION OF HARDWARE 2-1

- 1. ADAPTER BOX 2-1
- 2. CAMERA DESCRIPTION 2-2
- 3. Camera Signal Cable 2-4
- 4. USB Image Signal Cable 2-4
- 5. DC12V Power Supply 2-4
- 6. Network Cable 2-4

B. INSTALLATION OF SOFTWARE 2-5

- 1. SPECIFICATION OF COMPUTER 2-5
- 2. INSTALLATION 2-5

CHAPTER 3 GET A GLANCE

- OVERVIEW 3-1
- BASIC TOOLS BUTTONS 3-2
- SETTING TOOLS BUTTONS 3-3
- MEASURING TOOLS BUTTONS 3-4
- MEASURING CANVAS 3-5
- MONITORING WINDOWS 3-6
- DATA PANEL 3-7

CHAPTER 4 SETTINGS

DISPLAY	4-1
DISPLAY RESOLUTION	4-2
FINE-TUNE AND ROTATE CAD IMAGE	4-3
OBJECT SNAP MODE (Tracking)	4-5
HOW-TO	4-5
THE SNAP POINTS	4-6
MAIN SCREEN	4-6
READER (Position Reader)	4-7
DISPLAY MODE	4-8
Reader screen rotation	4-8
SCALE BAR	4-8
TILT CROSSHAIR	4-9
CIRCLE	4-9
RECT	4-9
POSITION IDENTIFICATION	4-10
SOURCE	4-11
COORDINATE SYNC. SOURCE DESCRIPTION	4-11
COORDINATE SYNC. CONNECTION DETAILS	4-13
MACHINE	4-15
DIRECTION	4-15
TRAVEL	4-16
PRECISION	4-16
NUMBERS ADDRESS	4-17
SIGN (Minus Sign)	4-17
TTC POSITION READER	4-18
1. HOW-TO	4-18
2. ADJUSTMENTS / MOVEMENTS	4-21
COLOR	4-25

CHAPTER 5 CALIBRATIONS

ADJUST THE BEST FOCUS FOR TTC CAMERA 5-1

HOW-TO 5-1

CALIBRATION OF TTC CAMERA 5-2

TOOLS 5-2

HOW-TO 5-2

UPDATE 5-5

USE CORRECT CAMERA MAGNIFICATION 5-5

FINE-TUNING THE CALIBRATION 5-6

HOW-TO 5-6

Calibration 5-8

Calibration timing 5-8

Tools preparation 5-8

Preparation 5-8

Camera's horizontal check 5-8

Horizontal calibration 5-9

Camera's centre point check 5-9

Centre point calibration 5-10

Precaution 5-11

CHAPTER 6 BASIC OPERATION

PREPARE TO START 6-1

START TOLTEC V7.0 6-2

ACTIVATOR 6-2

PAUSE 6-2

PROCEED 6-2

QUIT 6-2

SAVE		6-3
SAVE IMAGE	6-3	
SAVE DXF-CAD format	6-4	
SAVE EXCEL	6-4	
FILM RECORDING		6-5
DELETE		6-7
IMPORT CAD FILE		6-8
CREATE TOLERANCE LINES FOR CAD IMAGE		6-10

CHAPTER 7 MEASUREMENTS

THE MEASUREMENTS INCLUDE		7-1
POINT		7-2
HOW-TO	7-2	
LINE		7-3
HOW-TO	7-3	
SQUARE		7-4
HOW-TO	7-4	
CIRCLE		7-5
HOW-TO	7-5	
ARC		7-6
HOW-TO	7-6	
ANGLE		7-7
HOW-TO	7-7	
DESCRIPTION AS FOLLOWS	7-7	
VERTICAL DISTANCE (VD)		7-12
HOW-TO	7-12	
DESCRIPTION AS FOLLOWS	7-12	

CIRCLE COMPARISON	7-14
HOW-TO	7-14
FINE MOVEMENT	7-15
SQUARE COMPARISON	7-16
HOW-TO	7-16
FINE MOVEMENT	7-17
DPP (Distance Between Two Points)	7-19
HOW-TO	7-19
DPL (Distance Between A Point And ALine)	7-20
HOW-TO	7-20
POSITION ROTATION	7-21
HOW-TO	7-21
MEASUREMENT UNDER THE ROTATION	7-22
RESET THE ROTATION	7-22
CHAPTER 8 KEYBOARD SHORTCUT	
KEYBOARD SHORTCUT	8-1
ACTIVATE SHORTCUT	8-2
SHORTCUTS AND COMMANDS	8-2
DEACTIVATE SHORTCUT	8-3

CHAPTER 1

FEATURES

TOLTEC V7.0

- **Perform General Measurement Function**



POINT



ANGLE



LINE



HORIZONTAL DISTANCE



SQUARE



VERTICAL DISTANCE



CIRCLE



DPP



ARC



DPL

- **Definite the axes**

Of a point, a line (two ends), the centers of a circle, an arc and an angle.

- **Circle comparison and Square comparison**

Draw wanted circle or square to compare with the measuring piece.

- **CAD Comparison**

Determine the works by comparing with its CAD image

- **Measuring Range**

As the applied machine's full travel range.

- **Crosshair Rotation**

Rotating the crosshairs to parallel with workpiece.

- **Fine Tune**

Use the arrow keys of a keyboard to make fine movements of the cursor crosshair, allow the user to select the target precisely and can avoid the mistakes by hand.

- **Data Save and Export**

The measuring data can be saved as the 5 formats of .dxf (CAD), .jpg and .xls (Excel).

- **Position Sync**

Synchronizing the position data from the machine control vi network or monitoring.

- **Short-Cut**


Restrict the measuring tools to certain keyboards, the measuring operations can operate only by keyboard.

CHAPTER 2

INSTALLATIONS


A. INTRODUCTION OF HARDWARE

1. ADAPTER BOX



- | | |
|-------------------------|---------------------------------|
| 1.Camera Mount | 6.Camera Signal Cable Interface |
| 2.DC12V Input | 7.Main Light Knob |
| 3.Power Indicator Light | 8. Main Light/Laser Switch |
| 4.DC12V Output | 9.Auxiliary Light Knob |
| 5.USB Interface | |

2. CAMERA DESCRIPTION



1. Fixture (EROWA or 3R or NB or Customization)
2. Signal Output
3. Body
4. Main Light/Laser Switch
5. Main Light Knob
6. Main Light

CAMERA SPECIFICATION SHEET

ADVANCED SET/ PROFESSIONAL SET SPECIFICATION

Sensor	AR0134
Shutter	Global Shutter
Max. Image Circle	1/3"
Sensor Type	CMOS
Sensor Size	4.8mm x 3.6mm
Resolution (HxV)	1280px x 960px
Resolution	1.2MP
Pixel Size(HxV)	3.75 μ m x 3.75 μ m
Frame Rate	54 fps
Mono/Color	Mono

Camare Date

Interface	USB 3.0
Pixel Bit Depth	8, 12 bits
Synchronization	<ul style="list-style-type: none"> ▪ hardware trigger ▪ free-run ▪ software trigger
Exposure Control	▪ programmable via the camera API
Digital Input	1
Digital Output	2
General Purpose I/O	3
Power Requirements	▪ Via USB 3.0 interface
Power Consumption (typical)	1.2W
Operating	0-50°C

3. Camera Signal Cable



4. USB Image Signal Cable



5. DC12V Power Supply



6. Network Cable



SPECIFICATION

INPUT : 10-240VAC 50/60HZ 1.4A

OUTPUT : 12V 5A 60W


B. INSTALLATION OF SOFTWARE

1. SPECIFICATION OF COMPUTER


- a. WINDOWS System WIN 7,WIN8,WIN10
- b. Desktop with 15-inch or above monitor, or 15-inch or above notebook, or 15-inch or above tablet

2. INSTALLATION

1. Load the TOLTECV7.0 software into computer and open the folder.



2. Select "TOLTEC setup" and right-click, and select "Run as a system administrator(A)"



3. "Windows has protected your PC" is displayed, select "other information".


4. Select "Run anyway".



5. Select the installation directory and language, then click "Install"




6. The installation is complete, select "OK".



7. Install the camera driver.




8. Select "I agree to the pylon [Terms&Conditions](#)" .




9. Select "Next".

10. Select "Camera User".




11. Select "Next".

12. Select "USB".




13. Select "Next" .


14. Installation directory.




15. Check the installation object, select "Install" after confirmation.




16. Start to install the camera driver.




17. After completing installation, go back to "TOLTECV70_SETUP" folder, select Installation_2, and install Mitsubishicontroller driver.



18. Select "MitsubishiMachineCenter".




19. Select "Lisceince.txt"





20. The version serial number is displayed, please copy it.




21. Select "MitsubishiFCSB1224W00-CNC".



22. Select "FCSB1224-dev.exe", install execution program.



23. Enter name.



24. Paste the serial number.

FCSB1224W000 Development Environment - InstallShield Wizard

Input ProductID

Please enter the product ID of the product.
Please input in single byte English characters.

147 401150682

InstallShield

< Back Next > Cancel

FCSB1224W000 Development Environment - InstallShield Wizard

Choose Destination Location

Select folder where setup will install files.

Install FCSB1224W000 Development Environment to:
E:\Program Files\EZSocket



Change...

You can select the installation folder for the initial installation of this product. If this product is already installed, it will be installed and updated under the same folder. Installation itself will not be done if the existing one is newer.


InstallShield

< Back Next > Cancel


25. Select "Install" , start the installation.




26. The installation is completed.




27. Go back to "TOLTECV70_SETUP" folder, select Installation_3, install Heidenhain controller driver.




28. Select "RemoTools.msi" .



29. Start the installation.




30. The Installation is completed.



CHAPTER 3

GET A GLANCE

OVERVIEW



BASIC TOOLS BUTTONS



Activator (page 6-1)

When the program is started or paused, click Activator to active the program.



Delete (Page 6-4)

Delete the data and drawing on the Measuring Operation Area.



Pause (Page 6-1)

Freeze the Measuring Canvas and the Measuring Tools Buttons.



Import CAD File

(Page 6-6)



Quit (Page 6-2)

Close the program and all datathat are not saved will be lost.



Recorder

(Page 6-3)



Save (Page 6-2)

Save the results in 5 forms



Stop Recorder

SETTING TOOLS BUTTONS



Display

(Page 4-1)



Position

(Page 4-7)



Calibration

(Page 5-1)



Increase Brightness

for Perimeter Light of
TTC Camera



Reduce Brightness

for Perimeter Light of
TTC Camera



Colour Setting

(Page 4-18)



High contrast

for Perimeter Light of
TTC Camera



Low contrast

for Perimeter Light of
TTC Camera



Reduce Focus Ref.

(Page 5-5)

Range



Enlarge Focus Ref.

(Page 5-5)



Numbers Definition

(Page 4-14)

For position sync

MEASURING TOOLS BUTTONS



Point (Page 7-2)

X and Y axes of a point



VerticalDistance

(Page 7-9)

between two points



Line (Page 7-3)

Distance
between two points



Square and Circle

(Page 7-10/7-12)

Comparison



Square (Page 7-4)

The Axes and Diameter
of a Circle



DPP (Page 7-14)

Distance between
existing or new points



Circle (Page 7-5)

The Axes and Diameter
of a Circle



DPL (Page 7-15)

Distance between a
point or a line



Arc (Page 7-6)

The Axes, Radius and
arc of an Arc



Crosshairs Rotation

(Page 7-16)



Angle (Page 7-7)

The Axes and angle of
an Angle



Rotated Crosshairs

(Page 7-17)

Reversion




Horizontal Distance

(Page 7-8)

between twopoints

MEASURING CANVAS

The measurements can only be operated on this area, if you wish to measure beyond the scene, then you need to move the camera to the target area, and then continue the operation.




MONITORING WINDOWS



The double enlarged image of cursor crosshair focal area



The image via TTC Position Reader (Full range)



WARNING	
MACHINE	
MISMATCH	
X =	0.000
Y =	0.000
Z =	0.000
X	0.221
Y	0.298
Z	0.000
ARC P1	

The double enlarged image of cursor crosshair

The focus of cursor crosshair for enlarging

DATA PANEL

X - 136.530
Y - 58.250
Z - 176.620
X = 0.000
Y = 0.000
Z = 0.000
X - 136.496
Y - 59.602
Z - 176.620
POINT

Synchro Position datafrom
machine (XYZ)

Data of the last measurement

Position of the cursor crosshair

Current Measurement

CHAPTER 4

SETTINGS



DISPLAY

Display

Image
 Measured Date
 DXF Date
 Tolerance Peek
 DXF Fine-tune
 Mapping
 Mapping Fine-tune
 Tracking

Scale bar
 (micron/mil)

Tilt Crosshair
 Degree


TTC Camera
 Main Image
 1X 2X
OK
Cancel

Reader
 Reader
 BW Mode BW1 BW2
 Display Mode Normal BW

Crosshair
 Circle D micron
 Rect X Y

DISPLAY RESOLUTION

Check the figures you wish to display on the Measuring Canvas.
Or check again to deselect.



■ Image

The images shot via Toltec Camera

■ Measured Data



The measured results on the Measuring Area

■ DXF DATA

The imported CAD image
(see page 6-9)

○ Tolerance

Indicate the Tolerances with CAD lines (see page 6-9) in order to quickly determine the error of work. (see page 6-11)



1. The tolerance lines show in yellow.
2. The CAD line shows in red.

- **DXF Fine-tune**

Fine-tune to adjust the tolerance range.

To fine-tune the range by using the arrows on keyboard, the range will show on the top-rightpanel of screen.


FINE-TUNEAND ROTATE CAD IMAGE

1 Import a CAD image.

2 Click Display button.




3 Check **DXF Fine-tune**.




4 Make X-axis Deviation by pressing LEFT/RIGH Tarrow keys on the keyboard.



5 Make Y-axis Deviation by pressing UP/DOWN arrow keys on the keyboard.



- 6 Clockwise rotate the CAD image by pressing **Page Up** key.
- 7 Anti-clockwise rotate the CAD image by pressing **Page Down** key. 1 press = 0.01°



- 8 Check the deviation and rotation states.



- 9 Tick off the Fine-tune function when finish the adjustment.

■ Mapping


Check to show the Circle and Square comparisons figures.
(Page7-14 / 7-16)

○ Mapping Fine-tune

To fine-tune the circle/square position on Measuring Canvas

by using the arrows on keyboard. The movement will show on the Circle / Square comparison popup window.

(page 7-15 / 7-17 / 7-18)



OBJECT SNAP MODE (Tracking)

This mode is available for the measurements of Point, Line, Arc, Circle and Angle; allows the user to specify the snap points.

HOW-TO


1 Click **Display** button



2 Check **Tracking**

3 Click **OK**

4 Move the cursor on the figures on Measuring Operation Area.



THE SNAP POINTS


Point : 1 point (node).

Line : 3 points –two endpoints and one midpoint.

Arc : 4 points –two endpoints, one midpoint and node.


Circle : 5 points –quadrant (0, 90, 180 and 270) and center.

Angle : 1 points –node.



MAIN SCREEN


Camera device can be placed at 0/90/180/270-degree position on the machine tool, where the software can display position, select the current direction and position of the camera, so as not to cause the movement direction of machine to be opposite to the direction of camera.



1X camera 1x imaging
2X camera 1x imaging

READER (Position Reader)

Check Reader to switch the image provider to Position Reader, and to select the right "BW Mode" and "Display Mode".




- **BW Mode(BW1/BW2)**

The mode for the software to identify the digitals on the control is **White text on Black back ground**, therefore if the screen displays as Black text on White background, you need to switch between "BW1" and "BW2" to get the right mode.

- **Display Mode Normal:**

Use this mode for adjusting the best focus for the Reader. Once you get the best focus, and then change to BW.



Black text on White background


White text on Black background

- **BW :**

Use this mode for number identification. Display as White text on Black background or Black text on White background

DISPLAY MODE

- **Normal :**
Use this mode for adjusting the focus for the Position Reader.
Once you get the best focus, please change to BW.
- **BW :**
Use this mode for axis number identification setting.
The screen will display in two modes: white-on-black or black-on-white.




Reader screen rotation

Reader can be placed at 0/90/180/270-degrees position on the machine tool, where the software can display position, select the current direction and position of the camera, so as not to cause the movement direction of machine to be opposite to the direction of camera.

SCALE BAR

Place a Scale Bar on the Measuring Canvas in order to define the dimension of your target.




- 1 Click Display button.
- 2 Check the "Scale bar".
- 3 Input a value, the unit is in micron.

TILT CROSSHAIR

To rotate the crosshairs by checking and inputting the degree.


Tilt Crosshair Degree



CIRCLE

If you input a value at this position, a circle with radius in micron will be generated at the cursor crosshair center, and can be used to find the point position or circle comparison within the screen range.


Circle D



RECT

If you input a value at this position, a rectangle with length and width in micron will be generated at the cursor crosshair center, and can be used to find the point position or square comparison coordinate synchronization within the screen range.

Rect X Y





POSITION IDENTIFICATION

Position Identification

Source

AgieCharmilles Chmer Mitsubishi (wire) Makino
 Fanuc AccuteX Mitsubishi (EDM) Heidenhain
 Screen-Monitor Sodick SL/AL Mitsubishi (MC)
 Toltec-Reader Toltec-Counter

IP

Password

Port

Z

COM
Machine: 03199388

Machine

Direction

Y Z
 X X
 Y Z

Sync. On Off

Toltec-Reader

X - .

Y - .

Z - .

Reader Enable Disable

Unit mm Inch

Travel

< 1000 X Y Z
1000 - 9999

Precision

0.001 X Y Z
0.0001
0.00001
0.000001

Sign Fixed Floating

SOURCE

The sources of position data synchronization.

The screenshot shows a configuration window titled "Source" with the following elements:

- Radio buttons for machine types: AgieCharmilles, Chmer, Mitsubishi (wire), Makino, Fanuc, AccuteX, Mitsubishi (EDM), Heidenhain, Screen-Monitor, Sodick SL/AL, Mitsubishi (MC) (dropdown menu), and Toltec-Reader (selected).
- Toltec-Counter: Two input fields, both containing "0".
- IP: Input field containing "192.", followed by "ON" and "OFF" buttons, and the word "Static".
- Password: Input field containing "0318F740", followed by the word "Static" and an input field containing "0".
- Port: Input field containing "0".

COORDINATE SYNC. SOURCE DESCRIPTION

1. AgieCharmilles

AgieCharmilles Machine. It captures the coordinates via LAN, and you have to purchase Licence from AgieCharmilles in order to connect the machine.

2. Fanuc

Fanuc Controller. It requires fucas2 feature, and captures the coordinates via LAN. This is an optional feature of Fanuc, and you have to purchase Licence from Fanuc.

3. Software capture

SETTINGSScreenMonitor. This is a feature developed by TOLTEC, which is for machine and is an applet developed by the system after Windows XP, and can be installed in Windows to perform the coordinate capture function.

4. Reader capture

TOLTEC-Reader. This is a CCD coordinate capture feature developed by TOLTEC and is an option for machine which can't capture coordinates via LAN.

5. Chmer

Chmer Machine. It captures the coordinates via LAN.

6. AccuteX

AecuteX Machine. It captures the coordinates via LAN.

7. Sodick SL/AL

Sodick Machine. It is universally applicable for EDM Wirecut Machine Center, but Wirecut has SL and AL types and must be selected separately. It captures the coordinates via LAN, and it is a standard feature.

8. Mitsubishi(wire)

Mitsubishi WireCut. It captures the coordinates via LAN, Mitsubishi WireCut DNC is an option, and you have to purchase Licence from Mitsubishi.

9. Mitsubishi(EDM)

Mitsubishi EDM. It captures the coordinates via LAN, but Mitsubishi EDM DNC is a standard feature.

10. Mitsubishi(MC)

Mitsubishi Machine Center Controller. It captures the coordinates via LAN, and it is a standard feature.

11. Makino

MAKINO EDM WireCut. It captures the coordinates via LAN, and is an option. You have to purchase Lincence from MAKINO.

12. Heidenhain

Heidenhain Machine Center Controller. It captures the coordinates via LAN, and is an option. You have to purchase Lincence from Heidenhain.

COORDINATE SYNC. CONNECTION DETAILS

1 AgieChermilles

Source

AgieCharmilles Chmer Mitsubishi (wire) Makino
 Fanuc AccuteX Mitsubishi (EDM) Heidenhain
 Screen-Monitor SL/AL Mitsubishi (MC)
 Toltec-Reader Toltec-Counter 0 0

IP 192. ON OFF Static 0

Password 0318F740 Static 0

Port 0

2 Fanuc

Source

AgieCharmilles Chmer Mitsubishi (wire) Makino
 Fanuc AccuteX Mitsubishi (EDM) Heidenhain
 Screen-Monitor SL/AL Mitsubishi (MC)
 Toltec-Reader Toltec-Counter 0 0

IP 192. ON OFF Static 0

Password 0318F740 Static 0

Port 8193

3 ScreenMonitor

Source

AgieCharmilles Chmer Mitsubishi (wire) Makino
 Fanuc AccuteX Mitsubishi (EDM) Heidenhain
 Screen-Monitor Sodick SL/AL Mitsubishi (MC)
 Toltec-Reader Toltec-Counter

 Static

Password Static

Port

4 TOLTEC-Reader

Source

AgieCharmilles Chmer Mitsubishi (wire) Makino
 Fanuc AccuteX Mitsubishi (EDM) Heidenhain
 Toltec-Reader Sodick SL/AL Mitsubishi (MC)
 Toltec-Counter

 Static

Password Static

Port

Machine

Machine : 03199388

Direction

Y Z
 X X
 Y Z

Sync.

On
 Off

Toltec-Reader

X - 9999 . 99999999

Y - 9999 . 99999999

Z - 9999 . 99999999

Reader

Enable
 Disable

Unit

mm Inch

Travel

< 1000 X Y Z
 1000 - 9999

Precision


0.001 X Y Z
 0.0001
 0.00001
 0.000001

Sign

Fixed Floating

MACHINE

Save the setting for different Position Readers, it is convenient as you have several Position Readers sharing one Toltec V7.0 Program.



▪ Loading Setting

When your Toltec V7.0 program is used by different machine, you can easily get the setting parameter by giving the code to the "Machine" cell and then click **Load**

▪ Saving Setting

Once you finish the position Reader setting, you can save it by inputting a code to the cell and then click **Save**.

Machine: indicating the machine setting in use

DIRECTION

The Direction setting is according to the X/Y axis movements of a machine.

➤ X1:

X axis movement by Machine **Work Table**.

➤ Y1:



Y axis movement by Machine **Work Table**.

➤ X2:

X axis movement by Machine **Head**.

➤ Y2:

Y axis movement by Machine **Head**.



TRAVEL

The travel distance setting is for the Position identification.

Travel	X	Y	Z
< 1000	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>
1000 - 9999	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>

< 1000 :

Apply to the machine's travel distances less than 1000mm

1000-9999 :

Apply to the machine's travel distances between 1000 and 9999mm.

PRECISION

The selection is according to the machine's data.

If the machine's position data shows thousandths, select only 0.001. Likewise ten thousandths should select only 0.0001.

- Metric Unit: 3 or 4 decimal places (0.001 or 0.0001)
- Imperial unit: 5 or 6 decimal places (0.00001 or 0.000001)

Precision	X	Y	Z
0.001	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>
0.0001	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
0.00001	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
0.000001	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>

NUMBERS ADDRESS

Define the scope of the axes by giving the addresses to each number.

X-axis address

Y-axis address

Minus

Contro

298 0 443 608 748 0

373 510 676 0 0

X - 9 9 9 9 . 9 9 9 9 9 9

Y - 9 9 9 9 . 9 9 9 9 9 9

Z - 9 9 9 9 . 9 9 9 9 9 9

263 → Top Point

360 → Bottom Point

360 → Top Point

480 → Bottom Point

480 → Top Point

589 → Bottom Point

Cursor Axis Address

The addresses of the cursor on the screen can be found under the Number Definition button.

Number Definition Button

X axis addr. X 386

Y axis addr. Y 293

Definite Number

Number Addresses

Three addresses are needed for defining the scope of a number, including the centre, top and bottom points.

Top

Centre

Bottom

SIGN (Minus Sign)

Select the position of axis's minus sign as Fixed or Floating according to the machine control.

Sign

Fixed Floating

TTC POSITION READER

- With the TTC Position Reader the Software can synchronize the position data from the machines.
- Reader's stand is varied due to the variable machine models. Magnetic Base is used in this demonstration.


1. HOW-TO

- 1 Insert the Toltec V6.0 Protector and start the program.
 - 2 Tune on the Position Reader function
-


I. Click **Display** button



II. Check **Reader**



III. Check **Normal**




IV. Adjust Brightness and Contrast



V. Click **OK** to return to the main screen.

- 3 Find the **Best Reading Area** *
on the control.



Best Reading Area:


The centre of the crosshair should locate at the decimal point of Y axis. However the presentation of XYZ axes vary on different control, please find the central point on the position section accordingly.

The red crosshair (above) indicates the focus of TTC Reader (below).




- 4 Place the Magnetic Kit on the controller according to the Best Reading Area.


The Magnetic Block will be on the same vertical line as the Best Reading Area.



- 5 Adjust the Position Reader's angles by a Hex Key in order to get a right angle (90°) between the Reader and the control.



2. ADJUSTMENTS / MOVEMENTS



5 Chmer

Source

AgieCharmilles Chmer Mitsubishi (wire) Makino

Fanuc AccuteX Mitsubishi (EDM) Heidenhain

Screen-Monitor Sodick SL/AL Mitsubishi (MC)

Toltec-Reader Toltec-Counter

IP ON OFF Static RF Channel

Password Static

Port

6 AccuteX

Source

AgieCharmilles Chmer Mitsubishi (wire) Makino

Fanuc AccuteX Mitsubishi (EDM) Heidenhain

Screen-Monitor Sodick SL/AL Mitsubishi (MC)

Toltec-Reader Toltec-Counter

IP ON OFF Static RF Channel

Password Static

Port

7 Sodick

Source

AgieCharmilles Chmer Mitsubishi (wire) Makino

Fanuc AccuteX Mitsubishi (EDM) Heidenhain

Screen-Monitor Sodick SL/AL Mitsubishi (MC)

Toltec-Reader Toltec-Counter

IP ON OFF Static RF Channel

Password Static

Port

8 Mitsubishi WireCut

Source

AgieCharmilles Chmer Mitsubishi (wire) Makino
 Fanuc AccuteX Mitsubishi (EDM) Heidenhain
 Screen-Monitor Sodick SL/AL Mitsubishi (MC)
 Toltec-Reader Toltec-Counter

IP RF Channel

Password

Port

9 Mitsubishi EDM

Source

AgieCharmilles Chmer Mitsubishi (wire) Makino
 Fanuc AccuteX Mitsubishi (EDM) Heidenhain
 Screen-Monitor Sodick SL/AL Mitsubishi (MC)
 Toltec-Reader Toltec-Counter

IP RF Channel

Password

Port

10 Mitsubishi Machine Center

Source

AgieCharmilles Chmer Mitsubishi (wire) Makino
 Fanuc AccuteX Mitsubishi (EDM) Heidenhain
 Screen-Monitor Sodick SL/AL Mitsubishi (MC)
 Toltec-Reader Toltec-Counter

IP RF Channel

Password

Port

11 MAKINO EDM WireCut

Source

AgieCharmilles Chmer Mitsubishi (wire) Makino

Fanuc AccuteX Mitsubishi (EDM) Heidenhain

Screen-Monitor Sodick SL/AL Mitsubishi (MC)

Toltec-Reader Toltec-Counter

IP RF Channel

Password

Port

12 Heidenhain Machine Center

Source

AgieCharmilles Chmer Mitsubishi (wire) Makino

Fanuc AccuteX Mitsubishi (EDM) Heidenhain

Screen-Monitor Sodick SL/AL Mitsubishi (MC)

Toltec-Reader Toltec-Counter

IP RF Channel


Password

Port



COLOR

Six colours are available for the crosshairs, Marker, Data, .DXF lines and Scale bar.



- **Cursor Crosshair**


The crosshair is as a cursor

- **Central Crosshair**

On the centre of the Measuring Canvas.

- **Datum Crosshair**

Datum (Zero) Point on the Measuring Canvas



- Green: Cursor Crosshair
- Blue: Cntral Crosshair
- Red: Datum Crosshair

- **Marker**

The Measuring figure on the Measuring Canvas

- **Data**

The data of measuring results on the Measuring Canvas

- **DXF**


The imported CAD file

- **DXF Tolerance**

CAD Deviation Lines

- **Scale Bar**

Place on the bottom-right of the Measuring Canvas



- Red: Marker
- Blue: Data

CHAPTER 5

CALIBRATIONS



ADJUST THE BEST FOCUS FOR TTC CAMERA

Each camera has its own focus; moreover the surface of a workpiece is not always even flat, therefore to get a better image, user can use the F value and Focus Reference Range to adjust the TTC Camera's focus.

- **F Value**
F value indicates the focus value; it helps the user to adjust the camera to its best focus. The greater the value, the better focus the camera will get. So user can refer to the value to find the best focus.
- **Focus Reference Range**
The reference range is for calculating the F value, when the surface of a workpiece within the reference range is uneven; you can reduce the focus reference range in order to get a high F value.

HOW-TO

1 Adjust the Focus Reference Range

Click **Reduce Focus Reference Range** button  to reduce the reference range, or click **Enlarge Focus Reference Range** button  to enlarge the reference range.

2 Adjust the Focus for TTC Camera

First adjust the best focus by sight.
Then adjust the focus according to the F value.


CALIBRATION OF TTC CAMERA

Calibrate each TTC Camera for the first time use and check regularly.


TOOLS

- Standard Scale
- TTC Camera(50ST used for the following demo)

HOW-TO

- 1 Start Toltec V6 and click **Activator** 
- 2 Place the **Standard Scale** under the TTC Camera.
- 3 Adjust the image to get the best focus.

The range is about 4mm under TTC 50ST Camera (refer to the table below)




Standard Scale Ranges for TTC Cameras

TTC Camera	Max. Range
30x	5mm
50x	4mm
120x	1.8mm
250x	0.9mm

4 Click **Calibration** button 

5 Check **Calibration** and one row on the **Device** section, fill in a name.



TTC Camera Calibration

Update

	Name	Scale
<input type="radio"/>	1222	0.9
<input type="radio"/>	1235	1.712
<input checked="" type="radio"/>	50ST	1
<input type="radio"/>	1237	3.1
<input type="radio"/>	1238	4
<input type="radio"/>	1239	5
<input type="radio"/>	1240	6
<input type="radio"/>	1241	7
<input type="radio"/>	1242	8
<input type="radio"/>	1243	9


Calibration
 Fine-tune
 Device

Fine-tune
 Off On

Calibration
Distance
4

OK
Cancel

6 Fill in the reference value (**Distance**) to the Calibration section. (Refer to the Standard scale range for TTC Camera table; 4 in this example) and then click **OK**.




Calibration

Distance

4

- 7 Move the cursor crosshair to **the first calibration point** on the left of the scale (red circle) and left-click your mouse (or click **enter**).



- 8 Select the second calibration point (red circle) on the right of the scale.
- 9 Click OK and the parameter will be saved. (Scale)
- 10 Find the magnification parameter besides the calibration button.



- 11 To double-check the precision of the parameter by using “Horizontal Distance” Measurement to measure the real length through the Standard Scale.


(See HD Measurement, page 7-8)


How to make an accurate selection?

Move the cursor crosshair to the first selected point either on right edge or left edge of the line, then move the cursor to the second selected point, the same side as the first selected point (right or left).

UPDATE

When one camera has been calibrated but the data (Scale section) is not saved on the Device list. Save the data by updating the calibration.

- 1 Click **Calibration** button 
- 2 Check **Device** and **Update**.
Check one row on the Devicesection.
- 3 Fill in the Scale and then click **OK**.



TTC Camera Calibration

Device

Update

	Name	Scale
<input type="checkbox"/>	1222	0.9
<input type="checkbox"/>	1235	1.712
<input checked="" type="checkbox"/>	50ST	1
<input type="checkbox"/>	1237	3.1
<input type="checkbox"/>	1238	4
<input type="checkbox"/>	1239	5
<input type="checkbox"/>	1240	6
<input type="checkbox"/>	1241	7
<input type="checkbox"/>	1242	8
<input type="checkbox"/>	1243	9


Calibration
 Fine-tune
 Device


Fine-tune
 Off On

Calibration
Distance

USE CORRECT CAMERA MAGNIFICATION

If more than one camera share the same program, please check the calibration every time when use in order to get the results correct.

- 1 Click Calibration button 
- 2 Check Device. Select the camera by name.
- 3 Click OK.



TTC Camera Calibration

Device

Update

	Name	Scale
<input type="checkbox"/>	1222	0.9
<input type="checkbox"/>	1235	1.712
<input checked="" type="checkbox"/>	50ST	1
<input type="checkbox"/>	1237	3.1
<input type="checkbox"/>	1238	4
<input type="checkbox"/>	1239	5
<input type="checkbox"/>	1240	6
<input type="checkbox"/>	1241	7
<input type="checkbox"/>	1242	8
<input type="checkbox"/>	1243	9

Calibration
 Fine-tune
 Device


Fine-tune
 Off On


Calibration
Distance

FINE-TUNING THE CALIBRATION


If the error occurs after the calibration and double-check, the fine-tuning can be applied to correct.

HOW-TO

- 1 Click **Calibration** button 
- 2 Check **Fine-tune** and **On**.
Click **OK**.




- 3 Fine-tune buttons located on the calibration parameter panel Turn the value till it is correct.



- 4 Turn off the Fine-tune function.

Click **Calibration** button 

Check **Off** and click **OK** to finish.




Calibration

TTC Micro Measurement System has been completely calibrated with horizontal and centre point before leave the factory.


Calibration timing:

1. When camera undergoes any collision.
2. Please check the horizontal and centre point of the camera regularly to assure the accurate result of measurement.



Tools preparation:

1. One perfect square block with no chamfer and well perpendicularity
2. 2.55mm T handles Allen Wrenches



[Figure 5-1]

Preparation:

Parallel place the square block to the Machine X axis or Y axis of the machine on the platform


Camera's horizontal check:

1. Connect the camera to the machine and the TTC monitor
2. Move the crosshair to the edge of the block.
(figure 5-1) Observe the crosshair and the square block, if they are not parallel, please calibrate the camera.

Horizontal calibration:

1. Before adjustment, please draw out the rubber plugs on the corners of the camera. There is a M5 stoppage screw on each corner.
2. Connect the camera to the machine.
3. Take one T handles Allen Wrench and inserts it into one M5 screw and then take the other one insert into the diagonal M5 screw.
4. Move the crosshair of the camera to the edge of the block, and calibrate the horizontal by adjusting the M5 screws. (figure 6-1)
5. Slight unwinds the screw A & B and slight winds the screw C & D to make a clockwise rotation.
6. Slight winds the screw A & B and slight unwinds the screw C & D to make anticlockwise rotation.
7. Repeat the adjustment till the crosshair paralleled the square.



Please slight turn the screw to avoid destruction of the camera.



【 Figure 6-1】

Camera's centre point check:

1. Connect the camera to the machine and the monitor
2. Overlap the centre of the crosshair and a corner of the block.
(see the figure 7-1)
3. Zero the X & Y axes of the machine.





【 Figure 7-1】

4. Remove the camera and rotate it 180 degrees, reinsert the camera into the machine.

5. Observe the centre of the crosshair and the corner, if they are not overlapping this indicates the centre point of the camera has deviated. (see the figure 7-2)

6. Again overlap the centre of the crosshair with the corner of the block, obtain the deviation by checking the values of X & Y axes of the machine.

7. Please adjust the camera when the deviation is out of the tolerance range.(Refer to the table below)





[Figure 7-2]

Horizontal Deviation Tolerance Ranges:

Camera models	Tolerances
TTC 30 ST	0.02mm
TTC 30 LS	
TTC 50 ST	0.01mm
TTC 50 LS	
TTC 120 LS	0.005mm
TTC 250 LS	0.003mm

Centre point calibration:

1. Move the X & Y axes of the crosshair to the centre of the Camera and the machine, which is 1/2 of M & N. (see the figure 8-1)



[Figure 8-1]

2. Adjust the X & Y axes of the machine to zero.

3. To move the X axis of the crosshair tighten screw (A) and loosen screw (B), or loosen screw (A) and tighten screw (B).

(see the left figure 8-2)

4. To move the Y axis of the crosshair tighten screw (C) and loosen screw (D),

or loosen screw (C) and tighten screw (D).


(see the right figure 8-2)

5. Again remove the camera and rotate it 180 degrees, and then reinsert the camera into the machine.

6. Observe if the crosshair overlaps the corner of the block ◦

7. If not, please do the centre calibration again, start with step one till the crosshair overlaps the corner of the block.

Repeat the steps if necessary.



【Figure 8-2】

Centre Point Deviation Tolerance Ranges:

Camera models	Crosshair line	Tolerances
TTC 30 ST	0.007mm	0.014mm
TTC 30 LS	0.007mm	0.014mm
TTC 50 ST	0.005mm	0.010mm
TTC 50 LS	0.005mm	0.010mm
TTC 120 LS	0.002mm	0.004mm
TTC 250 LS	0.001mm	0.002mm

Precaution:

Please first calibrate horizontal and then centre point.

When calibrating the centre point, it might cause a declination to the horizontal. If this happens, please recalibrate the horizontal.

CHAPTER 6

BASIC OPERATION

PREPARE TO START

- 1 Connect TTC Camera to the computer which is turned off.
- 2 Set the Display resolution to **1024x768**
- 3 Insert the TOLTEC Software Protector V7.0



ACTIVATOR



DELETE



PAUSE



IMPORT CAD FILE



QUIT



RECORDER



SAVE



STOP RECORDER

START TOLTEC V7.0



ACTIVATOR

Click **Activator** button



PAUSE

To freeze the measuring function by clicking **Pause** button




PROCEED

To proceed the measuring function after pause by clicking **Activator** button



QUIT

- 1 Click **Quit** button
- 2 Click **OK** to quitor click **Cancel** to stay.




- 3 When quit the program, all unsaved data will be lost.



SAVE

Five files will be created when you save the data, including three image formats, a CAD format and an Excel format .


- 1 Click Save button



- 2 Select the format and click OK.
- 3 Give the file name and click Save.

SAVE IMAGE


Each selection will be saved as an individual file.





SAVE DXF-CAD format

On this section your selections will be exported as an individual dxf file.



Measured Data

Imported DXF

Square / Circle Comparison


Please note

- 1 Only the measuringdata of Point, Line, Circle, Arc and Angle can be saved as .dxf file.
- 2 When save in imageformats, the image range includes the image and the data only show on the Measuring Operation Area.



SAVE EXCEL

Measurement data are exported in Excel format.






FILM RECORDING

Allow users to record the operation of the programme.


- 1 Click **Recorder** button
- 2 The recording time shows beside the **Recorder** button




- 3 To stop the recording by clicking the **Recorder** button again.
- 4 Give a file name and click **Save** to save the video.



- 5 Processing the video file as .avi format



6 Click **OK** when the process is completed



Recording Time


- 1 Please note that the processing time will be as long as the recording time, therefore a short recording is advised.



DELETE


To delete the data on the Measuring Canvas.

- 1 Click **Delete** button



- 2 To delete all the data at once by checking 'All' and click **OK**.

Click **OK** again to confirm.



- 3 To delete individual datum by checking "Selected one", and click **OK**.

Left-click on the wanted data on Measuring Canvas, and click OK to confirm.

The data can be deleted one by one by left-clicking on the wanted data repeatedly.




- 4 Once all results are deleted on Measuring Canvas, it cannot be restored.




IMPORT CAD FILE

1 Click **Import DXF** button




2 Check "Load" and click **OK**.




PS. Import CAD file X Mirror / Y Mirror


3 Select the CAD file and click **Insert**.



4 "Loading OK", click OK.



5 The image show on the Measuring Canvas.



Important Information


- 1 The CAD entities for one file are up to 10,000, or the import will be failed.
- 2 Before export the CAD file for measuring, set the same datum point as the workpiece on machine, so the CAD image can overlap the workpiece perfectly on the Measuring Canvas




CREATE TOLERANCE LINES FOR CAD IMAGE

Set the tolerance lines for the CAD image on the Measuring Canvas for determining the deviation.


- 1 Click **DXF** button
- 2 Select **Tolerance** and click **OK**.



- 3 Input the values for the deviation range and click **OK**



- 4 Click on any CAD line, the deviation lines will be produced for the line.



I. the deviation circle lines show as the yellow lines.

II. The CAD circle line shows in red.

CHAPTER 7

MEASUREMENTS

THE MEASUREMENTS INCLUDE



Point



Horizontal Distance(HD)



Line



Vertical Distance(VD)



Square



Circle Comparison
Square Comparison



Circle



DPP (Distance Between
Two Points)



Arc



DPL (Distance Between A
Point and A Line)



Angle

• POINT

Define the axes X and Y of a point

HOW-TO

- 1 Click Point Button



POINT will be shown on Data panel.


- 2 Left-click on the target on the Measuring Canvas and the axes (X, Y) of the point will be shown on the screen.
-

Measuring Canvas



➤ P1: The first Point measurement

Data Panel



➤ X and Y axes of P1


Unselect the target

- 1 Unselect the point by pressing [backspace] on the keyboard.


LINE

To measure the length between two points.

HOW-TO

- 1 Click **Line Button** 
LINE will be shown on the Data panel.
- 2 Left-click on one point on the Measuring Canvas and then click another; a line will automatically be formed.
Or press "**backspace**" on keyboard to unselect the points.
- 3 Vertical-move the cursor from the line and left-click the distance will be shown on the Measuring Canvas and Data panel.

Measuring Canvas



- L1: The first Line measurement

Data Panel


```
X1 = 45.006
Y1 = -12.847
X2 = 45.265
Y2 = -12.694
L = 0.301
```

- X1/Y1 are the axes of the first point
- X2/Y2 are the axes of the second point.
- The length (L) is 0.301mm


SQUARE

To measure the centre's axes XY and the diameter of a square formed by 2 points.(diagonal point)

HOW-TO

- 1 Click **Square** Button 
RECT will be shown on the Data panel.
 - 2 Select two points by left-clicking on the Measuring Canvas.
Or press "**backspace**" on keyboard to unselect the points.
 - 3 Vertical move the mouse and Left-click for width.
Horizontal move and Left-click for length.
 - 4 The central axes and diameter will be shown on the Measuring Canvas and Data panel.
-

Measuring Canvas



- Q1: The first Square measurement


Data Panel

- Width: 0.173mm
- Length: 0.189mm
- The central axes of the circle
X -0.139
Y -0.115


CIRCLE

To measure the centre XY axes and diameter of a circle which is formed by 3 to 12 points.

HOW-TO

- 1 Click **Circle Button** 
CIRCLE will be shown on the Data panel.
 - 2 Select 3 to 12 points by left-clicking on the Measuring Operation Area.Or press "**backspace**" on keyboard to unselect the points.
 - 3 Right-click, a circle will automatically be formed.
 - 4 Left-click, the central axes and diameter will be shown on the Measuring Canvas and Data panel.
-

Measuring Canvas



- C1 : The first Circle measurement

Data Panel

X = 68.029
Y = -5.632
D = 0.551


- X and Y, the central axes of the circle.
- The diameter (D) is 0.551mm




ARC

To measure the Centre XY axes and radius of an arc which is formed by choosing 3 to 12 points.

HOW-TO

- 1 Click **Arc Button** 
ARC will be shown on the Data Panel .
 - 2 Select 3-12 points by left-clicking on the Measuring Operation Area. Or press "**backspace**" on keyboard to unselect the points.
 - 3 Right-click, an arc will automatically be formed.
 - 4 Left-click, the central axes, radius and arc will be shown on the Measuring Canvas and Data Panel.
-

Measuring Canvas



- Ar3 : The third Arc measurement

Data Panel

X = 66.498
Y = -5.735
R = 0.763
A = 146.746

- X and Y, the central axes of the arc
- The Radius (R) is 0.763mm
- The Arc (A) is 146.746



ANGLE

To measure the XY axes of intersection and angle degree of two lines.

HOW-TO


Angle There are three ways to measure angle.


1. the angle between two sloping lines
2. the angle between a sloping line and the horizontal line
3. the angle between a sloping line and the vertical line

DESCRIPTION AS FOLLOWS

1. THE ANGLE BETWEEN TWO SLOPING LINES

Operation Steps


- Click Angle button 
- Left-click separately on two points on a straight line of the Measuring Canvast to form the first line (If the selected point is not the correct one, press "backspace" on keyboard to unselect the point).
- Then left-click the mouse separately on the other two points on the Measuring Canvas to form another straight line, and these two lines will produce an intersection.
- Left-click the mouse again, to place the mark of angle between the two lines as shown below.




X	1.183
Y	0.638
A	183.997
ANGLE P1	

2. THE ANGLE BETWEEN A SLOPING LINE AND THE HORIZONTAL LINE

Operation Steps

- Click Angle button 
- Left-click separately on two points on a straight line of the Measuring Canvas to form the first line (If the selected point position is not the correct one, press "backspace" on keyboard (to unselect the point)).
- Right-click the mouse and there will be a hint of ANGLE P3 **V** on the right display field, and the **V** represents the angle between the line and the horizontal line. Choose the third point, then move the mouse toward the right or left to decide the desired angle direction, then click on the position where you want to place the angle. At this time, an intersection will be produced between the horizontal line and the angle line. °
- Left-click the mouse again, to place the mark of angle between the two lines as shown below.




X	0.430
Y	0.394
A	183.997
ANGLE P1 V	

3. THE ANGLE BETWEEN A SLOPING LINE AND THE VERTICAL LINE

Operation Steps

- a. Click Angle button
- b. Left-click separately on two points on a straight line of the Measuring Canvas to form the first line (If the selected point position is not the correct one, press "backspace" on keyboard to unselect the point).
- c. Right-click the mouse and there will be a hint of ANGLE P3 H on the right display field, and the H represents the angle between the line and the vertical line. Choose the third point, then move the mouse upward or downward to decide the desired angle direction, then click on the position where you want to place the angle. At this time, an intersection will be produced between the vertical line and the angle line.
- d. Left-click the mouse again, to place the mark of angle between the two lines as shown below.



X	0.430
Y	0.394
A	183.997
ANGLE P1 H	



HORIZONTAL DISTANCE (HD)

To measure the horizontal length between two points.

HOW-TO


Horizontal Distance(HD) There are two ways to take the measurement.


- 1.the horizontal distance between two points
- 2.the horizontal distance between the target point and the datum point.

DESCRIPTION AS FOLLOWS

1. THE HORIZONTAL DISTANCE BETWEEN TWO POINTS

Operation Steps


- a.Click **HORIZONTAL DISTANCE** button 
- b.Choose any two points on the Measuring Canvas to form a measurement line(If the selected position is not correct, press "backspace" on keyboard to unselect the point).
- c.Left-click the mouse to select the size mark and place it as shown below on the screen.




X1 =	-0.185
Y1 =	0.153
X2 =	-0.020
Y2 =	0.108
HD =	0.165
X	- 0.397
Y	0.042
Z	0.000
HD P1	

2. THE HORIZONTAL DISTANCE BETWEEN THE TARGET POINT AND THE DATUM POINT

Operation Steps

- a. Click HORIZONTAL DISTANCE button 
- b. Under the HORIZONTAL DISTANCE (HD) mode, **right-click** the mouse and there will be a hint of HDOP 2 on the right display field, and the **O** represents the datum point.
- c. Choose any point on the Measuring Canvas to form a measurement line (If the selected position is not correct, press "backspace" on keyboard to unselect the point).
- d. Left-click the mouse to select the size mark and place it as shown below on the screen.



datum point

X1 =	0.000
Y1 =	0.000
X2 =	0.174
Y2 =	0.152
HD =	0.174
X	- 0.275
Y	0.236
Z	0.000
HD	O P2



VERTICAL DISTANCE (VD)

To measure the vertical length between two points.

HOW-TO


Vertical Distance(VD) There are two ways to take the measurement


1. the vertical distance between two points
2. the vertical distance between the target point and the datum point

DESCRIPTION AS FOLLOWS

1. THE VERTICAL DISTANCE BETWEEN TWO POINTS

Operation Steps


- a. Click **VERTICAL DISTANCE** button 
- b. Choose any two points on the Measuring Canvas to form a measurement line (If the selected position is not correct, press "backspace" on keyboard to unselect the point).
- c. Left-click the mouse to select the size mark and place it as shown below on the screen




X1 =	0.171
Y1 =	0.083
X2 =	0.207
Y2 =	-0.038
HD =	0.100
X	- 0.178
Y	0.152
Z	0.000
HD P1	

2. THE VERTICAL DISTANCE BETWEEN THE TARGET POINT AND THE DATUM POINT

Operation Steps

- a. Click VERTICAL DISTANCE button 
- b. Under the VERTICALDISTANCE(VD) mode, right-click the mouse and there will be a hint of VDO P1 on the right display field, and the O represents the datum point.
- c. Choose any point on the Measuring Canvas to form a measurement line (If the selected position is not correct, press "backspace" on keyboard to unselect the point).
- d. Left-click the mouse to select the size mark and place it as shown below on the screen.



datum point



X1 =	0.000
Y1 =	0.000
X2 =	0.037
Y2 =	0.138
HD =	0.138
X	- 0.087
Y	0.064
Z	0.000
HD O P1	




CIRCLE COMPARISON

To measure actual Chamfer and the dimension and position of a circle.

HOW-TO

- 1 Click Display button 
- 2 Check **Mapping**, and then click OK
- 3 Click **Circle Comparison** Button 
- 4 Input the parameters, then click **OK**.





Mapping Setting							
	Line (1) :	X1	Y1	X2	Y2		
	Circle (2) :	CX	CY	D			
	Rect (3) :	CX	CY	LX	LY	A	R
1	<input type="text" value="0"/>	<input type="text" value="0"/>	<input type="text" value="0"/>	<input type="text" value="0"/>	<input type="text" value="0"/>	<input type="text" value="0"/>	<input type="text" value="0"/>
	a	b	c	d			
2	<input type="text" value="0"/>	<input type="text" value="0"/>	<input type="text" value="0"/>	<input type="text" value="0"/>	<input type="text" value="0"/>	<input type="text" value="0"/>	<input type="text" value="0"/>



- a. Input circle code : 2
 - b. Input circle centre coordinate (X)
 - c. Input circle centre coordinate (Y)
 - d. Input circle **diameter** (mm)
- 5 The circle will be formed on the Measuring Canvas according to the parameter.

FINE MOVEMENT

- 1 Click **Display** button 
- 2 Tick **Mapping Fine-tune**, and then click **OK**




- 3 Fine moving the circle by using the arrow keys on the keyboard
- 4 Click **Circle Comparison Button** 
- 5 Find the moving data on the Fine-tune section



- 6 Turn off the fine-tune function when you finish the moving.

6-1 Click **Display** button 

6-2 Tick off **Mapping Fine-tune**, and then click **OK**.





SQUARE COMPARISON


To measure the dimension and position of a square.

HOW-TO

1 Click Display button 

2 Check **Mapping**, and then click OK

3 Click **Square Comparison** Button 



4 Input the parameters, then click **OK**.

Mapping Setting						
Line(1) :	X1	Y1	X2	Y2		
Circle(2) :	CX	CY	D			
Rect(3) :	CX	CY	LX	LY	A	R
1	0 a	0 b	0 c	0 d	0 e	0 g
2	0	0	0	0	0	0
3	0	0	0	0	0	0

- Input circle code : 3
- Input circle centre coordinate (X)
- Input circle centre coordinate (Y)
- Input square **width** (mm)
- Input square **length** (mm)


- f. Input angel of square to the datum crosshair
- g. Input Radius

5 The circle will be formed on the Measuring Canvas according to the parameter.

FINE MOVEMENT

1 Click **Display** button 



2 Tick **Mapping Fine-tune**, and then click **OK**.



3 Fine moving the circle by using the arrow keys on the keyboard.

4 Click **Square Comparison** Button 


5 Find the moving data on the Fine-tune section.



6 Turn off the fine-tune function when you finish the moving.

6-1 Click **Display** button 

6-2 Tick off **Mapping Fine-tune**, and then click OK





DPP (Distance Between Two Points)

To measure the distance between two existing/new points or the centre axes of a circle, an arc or angle.

HOW-TO


- 1 Click **DPP** Button



DPP will be shown on the Data Panel.

- 2 Click on an existing or a new point on the Measuring Canvas, and then click on the other; a line will automatically be formed.
- 3 Vertical move the cursor from the line and then left-click, the length will be shown on the Measuring Canvas.

Measuring Canvas



- DPP between two circles

Data Panel

X1 = 0.506
Y1 = 1.518
X2 = 1.996
Y2 = 1.442
DPP 1.492

- X1/Y1 are the axes of the first point
- X2/Y2 are the axes of the second point.
- The length(DPP) is 1.492mm

Definition of an Existing Point


- 1 The existing points include the marked points of a point, a line, a circle, an arc and an angle.
- 2 Move the cursor crosshair onto an existing point and a small green square will appear on it, then you may click the point to select the point




DPL (Distance Between A Point And ALine)

To measure the distance between either an existing or a new point and an existing line.

HOW-TO

- 1 Click **DPL** Button 
DPP will be shown on the Data Panel.
- 2 Click on a point on the Measuring Canvas and then click on an existing line; a line will automatically be formed.
- 3 Vertical move the cursor from the line and then left click, the length will be shown on the Measuring Canvas.



- DPL between a point and a line

Data Panel

X1 = 5.702

Y1 = 9.042

Line 1

DPL = 0.701

- X1/Y1 are the axes of the existing points
- The length (DPL) is 0.701mm

Definition of an Existing Line


Move the cursor crosshair onto an existing line and the line becomes green, then you may click on the line for measuring.




POSITION ROTATION

To rotate the cursor/central/datum crosshairs. When the workpiece is not positioning on the machine, rotate the crosshairs to be paralleled with the workpiece and measure accordingly.



HOW-TO

- 1 Click **Position Rotation** button 
- 2 Left-click two points on a straight line or the edge of the workpiece.
- 3 The crosshairs will be rotated according to the two points gradient and parallel with the workpiece.


The rotated angle can be found on the panel.



First point



second point



- The new yellow rotated crosshair is paralleled with the rotated position.

- 1 The farther of the two selected points, the more precise angle you will get.
- 2 If the target is beyond the Measuring Canvas, move the TTC camera to get the farthest point.

MEASUREMENT UNDER THE ROTATION

When the new rotation has been made, you can perform all the measurements under this mode.

All results are obtained according to the new fiducial line.

The measurements under this mode will be less accurate when compare with the default mode.

RESET THE ROTATION

To reset the crosshairs to the default mode by clicking **Rotation Reset** button.



CHAPTER 8


KEYBOARD SHORTCUT


Active Keyboard Shortcut Mode(KSM)when operate the measurements without a mouse.

Under KSM, only certain keys are active and the cursor crosshair function will be ceasedsimultaneously .

The mouse only malfunctions on the Measuring Canvas, and it is still working for settings and basic operations.

ACTIVATE SHORTCUT



To activate the Keyboard shortcutmode by clicking M button on the keyboard. 



- White areas: active keys
- Blue areas: ceased keys

SHORTCUTS AND COMMANDS

SHORTCUT	COMMAND
M	Turn ON/OFF Shortcut function
0	POINT measurement
1	LINE measurement
2	SQUARE measurement
3	CIRCLE measurement
4	ARC measurement
5	ANGLE measurement

SHORTCUT	COMMAND
6	HORIZONTAL measurement
7	VERTICAL measurement
8	DPP measurement
9	DPL measurement
+	Saved image comparison 
Backspace	Deselect points
Esc	Close the toolbar window
End	As Right-click mouse (confirm the points selection) under CIRCLE and ARC measurement
Enter	Select points/confirm selection (as Left-click)
S	SAVE data
	Run theDXF file for fine-tuning To fine-tune the Square/Circle comparison figures

DEACTIVATE SHORTCUT

To deactivate the keyboard shortcut mode by clicking M button on the keyboard. 